



Fig.37

Fig. No.	Description	Part No.	Qt
<u>INSTRUMENTS</u>			
	<u>Combined instrument</u> , cpl. (km)	89960 ¹⁾	1
	<u>Combined instrument</u> , cpl. (miles)	651788 ²⁾	1
	<u>Combined instrument</u> , cpl. (km)	656087 ³⁾	1
	<u>Combined instrument</u> , cpl. (miles)	656092 ⁴⁾	1
37- 1	. Rear casing	89976	1
37- 2	. Marking plate	658288	1
37- 3	. Forward casing (chromed)	89977	1
37- 4	. Lens	88666	1
37- 5	. Scale for speedometer 89422 (km)	89419	1
	. Scale for speedometer 651931 (miles)	651928	1
	. Scale for speedometer 656090 (km)	656091	1
37- 6	. Lens for oil and ammeter 89967 (km)	89420	1
	. Lens for oil and ammeter 89967 (miles)	651929	1
	. Lens for oil and ammeter 656088 (km)	656089	1
	. Lens for oil and ammeter 656088 (miles)	656093	1
37- 7	. Lens for fuel and temperature gauges (km)	89421	1
	. Lens for fuel and temperature gauges (miles)	651930	1
37- 8	. <u>Speedometer</u> , cpl., for combined instrument No. 89960	89422	1
	. <u>Speedometer</u> , cpl., for combined instruments Nos. 651788 and 656092	651931	1
	. <u>Speedometer</u> , cpl., for combined instrument No. 656087	656090	1
37- 9	. . Nut	150139	1
37-10	. . Washer	120647	1
37-11	. <u>Ammeter</u> , cpl.	89966	1
37-12	. . Insulating washer	89424	2
37-13	. . Base washer	120608	2
37-14	. . Nut	906546	4
37-15	. . Lock washer	951693	2
37-16	. . Washer (brass)	11988	2
37-17	. <u>Oil pressure gauge</u> , for combined instruments Nos. 89960 and 651788	89967	1
	. <u>Oil pressure gauge</u> , for combined instruments Nos. 656087 and 656092	656088	1
37-18	. <u>Fuel gauge</u> , cpl.	89968	1
37-19	. . Protector	89427	2
37-20	. . Base washer	18709	2
37-21	. . Nut	19629	3
37-22	. . Washer (brass)	120080	3
37-23	. . Nut	89428	2
37-24	. <u>Temperature gauge</u>	89969	1
37-25	Connecting nipple	16212	1
37-26	Screw	115001	13

1. Up to chassis No. 155548. Replaced by 656087.

2. Up to chassis No. 147080. Replaced by 656092.

3. W.e.f. chassis No. 155549.

4. W.e.f. 147081.

* State required length.

Instruments

Fig. No.	Description	Part No.	Qty.
	<u>Steel piping</u> for oil pressure gauge	954312	*
	Screw union	26699	1
	<u>Hose</u> , pipe for oil pressure gauge - cylinder head	87970	1
	Screw union in cylinder head	180110	1
	Screw union at firewall	88018	1
	Screw	190666	1
	Clamp for combined instrument	94517	2
	Nut	906574	2
	Spring washer	906985	2
	<u>Mask</u> for instrument	94516	1
	Screw	902259	1
	Washer	11961	1
	Lock washer	951695	1
	<u>Switch</u> for instrument lighting	88281	1
	Screw	950008	2
	. Lock washer	951692	2
	<u>Speedometer cable</u> , cpl.	89243	1
	. Drive cable	89454	1
	Gasket for speedometer cable	191058	1
	Screw for speedometer cable, at H6 transmission	902251	1
	Screw for speedometer cable, at M4 transmission	921803	1
	Spring washer, H6 transmission	906987	1
	Spring washer, M4 transmission	906988	1
	Rubber bushing for speedometer cable	89047	1
	Screw	107401	1

* State required length.